

NanoVIP® CUBE 247™



Analizzatore della Qualità dell'Energia per sistemi monofase, bifase, trifase (bilanciati e non), in bassa e media tensione con connettività GSM 3G™ per una comunicazione senza limitazioni.

Power Quality analyzer for mono, bi, three phases (balanced and unbalanced), medium and low voltages systems with 3G™ technology to guarantee unlimited connectivity.



POTENTE, PRECISO, SEMPRE CONNESSO

- ✓ Utilizzabile su impianti: monofase, bifase, trifase equilibrato con o senza neutro, trifase squilibrato con o senza neutro
- ✓ Analisi energetica tradizionale completa (V, I, P, Q, S, F, PF, THD%, valori istantanei / minimi / massimi / medi / contatori di energia assorbita e generata sia trifase che per ogni singola fase).
- ✓ Analisi dei parametri di qualità dell'energia
- ✓ Armoniche di corrente e tensione per ogni fase e per il neutro fino alla 50° (7° a 400Hz)
- ✓ Sbilanciamento delle fasi di tensione
- ✓ Interruzioni di rete, sovratensioni, buchi di tensione
- ✓ Test di conformità alla normativa EN 50160
- ✓ Misura reale della corrente di neutro
- ✓ Visualizzazione delle forme d'onda di correnti e tensioni
- ✓ Impostazione di 4 fasce tariffarie con visualizzazione dei relativi costi
- ✓ Configurazione e visualizzazione di 20 allarmi su grandezze e soglie impostabili
- ✓ Visualizzazione dell'andamento nel tempo di grandezze selezionabili (trend)
- ✓ Check automatico del corretto collegamento dello strumento all'impianto
- ✓ Realizzazione di campagne di misura di lunga durata (oltre 24h in autonomia, illimitato se collegato alla rete)
- ✓ Batterie ricaricabili ad alta capacità che garantiscono oltre 24h di lavoro in modalità AirPlane e oltre 8h in connessione continua alla rete.
- ✓ Connessione al cloud Elcontrol

NanoVIP® CUBE 247™ è un potente e versatile analizzatore della Qualità dell'Energia che, oltre a svolgere misure e campagne autonome, può connettersi alla rete 3G garantendo il massimo della connettività. E' possibile l'upgrade hardware da un sistema NanoVIP® CUBE™ a NanoVIP® CUBE 247™.

EN

The **NanoVIP® CUBE 247™** is a powerful and versatile Power Quality analyzer that, thanks to the implementation of 3G™ technology, guarantees an unlimited connectivity. It is possible to upgrade latest NanoVIP® CUBE™ models to NanoVIP® CUBE 247™.

POWERFUL, PRECISE, ALWAYS CONNECTED

- ✓ Can work on networks: single-phase, two-phase, three-phase balanced with or without neutral, three-phase unbalanced with or without neutral
- ✓ Full traditional energy analysis (V, I, P, Q, S, F, PF, THD%, instantaneous values / minimum / maximum / average, energy meters absorbed and generated both three-phase for each phase).
- ✓ Analysis of power quality parameters
- ✓ The current and voltage harmonics for each phase and for the neutral up to 50°
- ✓ Imbalance of power phases
- ✓ Network outages, surges, sags
- ✓ Conformance testing to EN 50160
- ✓ Real measurement of the neutral current
- ✓ Display of the waveforms of currents and voltages
- ✓ 4 tariff bands setting with the related costs display
- ✓ Configuration and display of alarms on sizes 20 and settable
- ✓ Display of the time course of selectable parameters (trend)
- ✓ Automatic check of the correct connection of the implant tool
- ✓ Capable to do long-term measurement campaigns (over 24 independently, unlimited if connected to the network)
- ✓ High capacity rechargeable batteries that guarantees over 24h of work in Airplane Mode and over 8h in continuous 3G connection.
- ✓ Ready to connect to Elcontrol Cloud

NanoVIP® CUBE 247™

CASE:

| | |
|------------------|--------------------------------------|
| Dimensions | 203x116x53mm |
| Material | ABS with self-extinguishing V0 grade |
| Protection class | IP30 |
| Weight | 580 g |

DISPLAY:

| | |
|------------|---|
| Dimensions | 68x68mm |
| Type | 128x128 FSTN Negative dot matrix graphic LCD |
| Backlight | White LED |
| Languages | English - Spanish - Italian - German - French |

KEYPAD:

| | |
|------|--|
| Type | Membrane keypad with 10 double-function keys |
|------|--|

POWER SUPPLY:

| | |
|--------------------------------|---|
| External power supply | wall-plug switching; input 100-240VAC ±10% 47-63Hz with interchangeable plug; output 7.5VDC - 12W |
| Battery pack | 4 x AA NiMh 2100mAh |
| Duration of the battery charge | >24h (Airplane mode), >8h in continuous connection |

CONNECTING SYSTEMS:

| | |
|----------------------------------|---------------------|
| Systems frequencies | 50Hz - 60Hz - 400Hz |
| Single phase | ✓ |
| Two phase | ✓ |
| Three-phase, 3-wires, balanced | ✓ |
| Three-phase, 3-wires, unbalanced | ✓ |
| 4-phase, 4-wires, balanced | ✓ |
| 4-phase, 4-wires, unbalanced | ✓ |

CONNECTIONS:

| | |
|-----------------|--|
| Voltages | Flexible cables L = 1.5m; 2.5mm² - 36A; 1000V CAT III - 600V CAT IV with a 4mm, 90° protected blade plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors |
| Currents | Elcontrol Energy Net interchangeable amperometric sensors |
| Solar radiation | - |
| PT100 | - |
| Anemometer | - |
| Transducers | - |

FUNCTIONS:

| | |
|---------------------------------|--|
| Traditional electrical analysis | V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. |
| Neutral current | Measured |
| Three phase counters | kWh, kVAh, kWh, both absorbed that generated |
| Counters for each single phase | kWh, kVAh, kWh, both absorbed that generated |
| Cogeneration | ✓ |
| Waveforms | V & I |
| Harmonics | Values and histograms up to the 50th order |
| Sags | Dips, swells & interruptions |
| Transients | Overshoots & overcurrents |
| Unbalance | ✓ |
| Test EN 50160 | ✓ |
| Inrush current | ✓ |
| DC measures | ✓ |
| K factor | Up to the 25th order |
| Alarms | Displayed |
| Alarms log | 5 at display |
| Tariff bands | 4 |
| Energy costs | ✓ |
| IEC 61724 network parameters | - |

NanoVIP® CUBE 247™

| | |
|---------------------------------------|---|
| Test EN 82.25 | - |
| OSU™ (One Shot UPS) | ✓ |
| Measurement campaigns | unlimited, up to fill the memory card |
| MEASUREMENTS: | |
| Sampling frequency | 128 samples per cycle (adaptive in 40Hz-70Hz range) 16 samples per cycle at 400Hz |
| Data record rate | 1 sec. |
| Data storage rate | User selectable: 1", 5", 3", 1', 5', 15' |
| Type of connections available | Three-phase (3 or 4 leads), two-phase (2 leads), and single phase grid |
| Type of grid which can be connected | Low and medium voltage (LV and MV) |
| VOLTAGE (TRMS) | |
| Channels | 3 channels with common neutral + 1 independent, auxiliary channel |
| Input impedance | 4 Mohm |
| Scales | 2 |
| Direct measurement | Phase-phase: 7-1000VAC 40-70Hz Phase-neutral: 5-600VAC 40-70Hz Aux: 5-1000VAC 40-70Hz, 10-1400VDC |
| Measurement with VT | Ratio: 1-60000 Maximum value which can be displayed: 20MV |
| Permanent overload | Phase-phase: 1200VAC Phase-neutral: 700VAC Aux: 1200VAC, 1700VDC |
| Sensitivity | 5VAC Phase-neutral, 7VAC Phase-phase, 10VDC |
| CURRENT (TRMS) | |
| Channels | 5 independent channels |
| Input impedance | 10KOhm |
| Scales | 4 |
| Measurement with current clamps | Ratio: 1-60000 Maximum value which can be displayed: 500KA |
| Sensitivity | 0.2% of F.S. |
| POWERS | |
| Single phase power | Values < 999 GW, Gvar, GVA |
| Total power | Values < 999 GW, Gvar, GVA |
| POWER COUNTERS | |
| Maximum value before reset | 99999999 kWh, kvarh, kVAh |
| ACCURACY | |
| RMS voltages: | Scale 1 ±0.25% + 0.1%FS ⁽²⁾ @ RMS V < 350VAC ⁽¹⁾ Scale 2 ±0.25% + 0.05%FS ⁽²⁾ @ RMS V > 350VAC ⁽¹⁾ |
| RMS currents: | Scale 1 ±0.25% + 0.1%FS ⁽²⁾ @ RMS I < 5% IN clamp ⁽¹⁾ Scale 2 ±0.25% + 0.05%FS ⁽²⁾ @ 5% < RMS I < 20% IN clamp ⁽¹⁾ Scale 3 ±0.25% + 0.05%FS ⁽²⁾ @ 20% < RMS I < 50% IN clamp ⁽¹⁾ Scale 4 ±0.25% + 0.05%FS ⁽²⁾ @ > 50% IN clamp ⁽¹⁾ Power ±0.5% + 0.05%FS ⁽²⁾ |
| Power Factor (PF) | ±0.5° |
| Frequency | ±0.01 Hz (40-70Hz) |
| Active power count (kW) | Class 0.5 |
| Reactive power count (kVar) | Class 1 |
| HARMONIC ANALYSIS | |
| Up to 50 th order | |
| Up to 7 th at 400Hz | |
| ANALYSIS of EN50160 parameters | |
| Interruptions | >500ms |
| Dips | >500ms |

NanoVIP® CUBE 247™

| | |
|--|--|
| Swells | >500mS |
| Transient ANALYSIS | |
| Swells and overcurrents | >150uS |
| Inrush current analysis | RMS continuous sampling every 2 periods – Duration 1, 2, 5, 10 sec. |
| COMMUNICATION: | |
| MRH™ | - |
| Server mode | - |
| Connectable MRH™ clients | - |
| Client mode | - |
| Zigbee® | ✓ |
| Maximum distance outdoor | 600m (point to point) |
| Maximum distance indoor | 60m (point to point) |
| Mesh network | ✓ |
| WiFi | - |
| 3G | ✓ |
| Wireless to PC | - |
| Cloud connectivity | ✓ |
| Remote control | - |
| USB | to PC |
| DATA STORAGE: | |
| Internal memory | 64kB |
| External memory | Micro SD (4GB included) |
| OPERATING CONDITIONS: | |
| Operating temperature | -10 to +55 °C |
| Storage temperature | -20 to +85 °C |
| Relative humidity | Max 95% |
| Maximum altitude a.s.l. (600V CAT III) | 2000 m |
| EC COMPLIANCE: | |
| Directives | 93/68/EEC (Low Voltage Electrical Equipment); 89/336/EEC and 2004/108/EC (EMC - Electromagnetic Compatibility); 2006/95/EC - 72/23/EEC (LVD - Low Voltage Directive); 2002/95/EC (RoHS - Restriction of Hazardous Substances); 2002/96/EC and 2003/108/EC (WEEE - Waste Electrical and Electronic Equipment); IEC 61724 |
| REFERENCE STANDARDS: | |
| Safety | EN 61010-1 |
| Electromagnetic Compatibility (EMC) | EN 61326 EN 61326/A1 EN 61326/A2 EN 61326/A3 |
| Temperature | IEC 60068-2-1 (Operating temperature) IEC 60068-2-2 (Storing temperature) |
| Vibrations | IEC 60068-2-6 |
| Humidity | IEC 60068-2-30 (Humidity) |
| Overload | IEC 60947-1 |